

Telement Ltd - Original LG Spare Parts List

Tel : 0208 749 7777 E-Mail : info@telement.co.uk

www.telement.co.uk

**All parts are 100% Original and come in their original factory packaging.
Please contact us with part number and required qty and we will provide
you with a competitive quote.**

MODEL	PART NUMBER	DESCRIPTION
B2000	EXSK0006501	VCTCXO.ERF3004A.13 MHz
B2000	SJMY0007001	VIBRATOR
B2000	SUMY0003802	MICROPHONE
B2000	ACGM0044201	COVER ASSY.REAR
B2000	AKAZ0007502	KEYPAD ASSY
B2000	MCJA0013801	COVER.BATTERY
B2000	SMPY0008901	PAM
B2000	SGEY0003503	EAR PHONE/EAR MIKE SET
B2000	SSAD0007828	ADAPTOR.AC-DC
B2000	SBPL0077901	BATTERY PACK.LI-ION
B2000	SVLY0025501	LCD
B2000	SAGY0236866	PCB ASSY.MAIN.AUTO
B2000L	EXSK0006501	VCTCXO.ERF3004A.13 MHz
B2000L	SJMY0007001	VIBRATOR
B2000L	SUMY0003802	MICROPHONE
B2000L	ACGM0044201	COVER ASSY.REAR
B2000L	AKAZ0007502	KEYPAD ASSY
B2000L	MCJA0013801	COVER.BATTERY
B2000L	SMPY0008901	PAM
B2000L	SGEY0003503	EAR PHONE/EAR MIKE SET
B2000L	ACGK0044602	COVER ASSY.FRONT
B2000L	SSAD0007828	ADAPTOR.AC-DC
B2000L	SBPL0077901	BATTERY PACK.LI-ION
B2000L	SVLY0025501	LCD
B2000L	SAGY0236866	PCB ASSY.MAIN.AUTO
B2100	ACGM0046601	COVER ASSY.REAR
B2100	EXSK0006501	VCTCXO.ERF3004A.13 MHz
B2100	SJMY0007001	VIBRATOR
B2100	SUMY0003802	MICROPHONE
B2100	SGEY0003203	EAR PHONE/EAR MIKE SET
B2100	SMPY0008901	PAM
B2100	AKAZ0008102	KEYPAD ASSY
B2100	SSAD0007828	ADAPTOR.AC-DC
B2100	SBPL0077901	BATTERY PACK.LI-ION
B2100	SVLY0025501	LCD
B2100	SAGY0238104	PCB ASSY.MAIN
C1100	AKAZ0004506	KEYPAD ASSY
C1100	MDAM0005001	DECO.WINDOW(SUB)
C1100	SGEY0003203	EAR PHONE/EAR MIKE SET
C1100	SJMY0002802	VIBRATOR.MOTOR
C1100	ACGH0020601	COVER ASSY.FOLDER(LOWER)
C1100	ACGK0036801	COVER ASSY.FRONT
C1100	ACGM0029801	COVER ASSY.REAR
C1100	ACGJ0029801	COVER ASSY.FOLDER(UPPER)
C1100	EXSK0000801	VCTCXO
C1100	SACY0017002	PCB ASSY.FLEXIBLE

C1100	SMPY0004001	PAM
C1100	SSAD0007828	ADAPTOR.AC-DC
C1100	SBPL0072128	BATTERY PACK.LI-ION
C1100	SVLY0018801	LCD
C1100	SAGY0238167	PCB ASSY.MAIN
C1150	ACGH0036201	COVER ASSY.FOLDER(LOWER)
C1150	ACGK0057601	COVER ASSY.FRONT
C1150	AKAZ0004506	KEYPAD ASSY
C1150	EXSK0003501	VCTCXO.CSX-532-K01
C1150	SGEY0003203	EAR PHONE/EAR MIKE SET
C1150	SJMY0002802	VIBRATOR.MOTOR
C1150	ACGM0058301	COVER ASSY.REAR
C1150	SMPY0007201	PAM
C1150	ACGJ0047701	COVER ASSY.FOLDER(UPPER)
C1150	SACE0033101	PCB ASSY.FLEXIBLE.SMT
C1150	SSAD0007828	ADAPTOR.AC-DC
C1150	EUSY0285101	IC.TV00570003DAGB
C1150	SBPP0013101	BATTERY PACK.LI-POLYMER
C1150	SVLY0018801	LCD
C1150	SAGY0229493	PCB ASSY.MAIN
C2200	MWAC0041101	WINDOW.LCD
C2200	ABGA0002704	BUTTON ASSY.DIAL
C2200	EXSK0003501	VCTCXO.CSX-532-K01
C2200	SJMY0003601	VIBRATOR.MOTOR
C2200	ACGH0024301	COVER ASSY.FOLDER(LOWER)
C2200	SGEY0002901	EAR PHONE/EAR MIKE SET
C2200	ACGK0038001	COVER ASSY.FRONT
C2200	SACY0023501	PCB ASSY.FLEXIBLE
C2200	ACGJ0034801	COVER ASSY.FOLDER(UPPER)
C2200	ACGM0037202	COVER ASSY.REAR
C2200	SMPY0004001	PAM
C2200	SSAD0007828	ADAPTOR.AC-DC
C2200	EUSY0111601	IC
C2200	SBPL0072192	BATTERY PACK.LI-ION
C2200	SVCY0003601	CAMERA
C2200	SVLM0009701	LCD MODULE
C2200	SAGY0225325	PCB ASSY.MAIN FOR GREECE TIM
C2200	SAGY0221495	PCB ASSY.MAIN FOR ITALY TIM
C3300	EXSK0005002	VCTCXO.TG-5000LA(26MHZ)
C3300	SGEY0003204	EAR PHONE/EAR MIKE SET
C3300	SJMY0002602	VIBRATOR.MOTOR
C3300	ACGM0042703	COVER ASSY.REAR
C3300	ACGH0027703	COVER ASSY.FOLDER(LOWER)
C3300	AWAB0012602	WINDOW ASSY.LCD
C3300	SMPY0007201	PAM
C3300	ACGJ0039103	COVER ASSY.FOLDER(UPPER)
C3300	ACGK0042903	COVER ASSY.FRONT
C3300	ABGA0003611	BUTTON ASSY.DIAL
C3300	SSAD0007828	ADAPTOR.AC-DC
C3300	SBPL0076308	BATTERY PACK.LI-ION
C3300	SVCY0004001	CAMERA
C3300	SACE0023802	PCB ASSY.FLEXIBLE.SMT
C3300	EUSY0206101	IC.PF38F3050L0ZBQ0
C3300	SVLY0025301	LCD
C3300	SAGY0225380	PCB ASSY.MAIN

F2100	EUSY0188102	IC.LTC3205XEUF
F2100	EXSK0005501	VCTCXO.VT-R32250FR.26 MHz
F2100	MWAC0039601	WINDOW.LCD
F2100	SJMY0007002	VIBRATOR.MOTOR
F2100	SUMY0003807	MICROPHONE
F2100	MHFD0008301	HINGE.FOLDER
F2100	ACGH0023202	COVER ASSY.FOLDER(LOWER)
F2100	SGEY0004501	EAR PHONE/EAR MIKE SET
F2100	ACGJ0033802	COVER ASSY.FOLDER(UPPER)
F2100	ACGK0036602	COVER ASSY.FRONT
F2100	ACGM0036002	COVER ASSY.REAR
F2100	MBJA0014102	BUTTON.DIAL
F2100	SACY0023701	PCB ASSY.FLEXIBLE
F2100	SMPY0004001	PAM
F2100	SSAD0007828	ADAPTOR.AC-DC
F2100	SBPL0076303	BATTERY PACK.LI-ION
F2100	EUSY0181601	IC
F2100	SVCY0002801	CAMERA
F2100	EUSY0185501	IC.PF38F3350LLZDQ0
F2100	SVLM0007501	LCD MODULE
F2100	SVLM0008501	LCD MODULE
F2100	SAGY0222402	PCB ASSY.MAIN
F2400	EXSK0005002	VCTCXO.TG-5000LA(26MHZ)
F2400	ACGH0027201	COVER ASSY.FOLDER(LOWER)
F2400	ACGH0027204	COVER ASSY.FOLDER(LOWER)
F2400	ACGH0032201	COVER ASSY.FOLDER(LOWER)
F2400	ACGJ0038601	COVER ASSY.FOLDER(UPPER)
F2400	ACGJ0038604	COVER ASSY.FOLDER(UPPER)
F2400	ACGJ0043801	COVER ASSY.FOLDER(UPPER)
F2400	SGEY0003203	EAR PHONE/EAR MIKE SET
F2400	ACGM0048001	COVER ASSY.REAR
F2400	ACGM0054703	COVER ASSY.REAR
F2400	AWAB0012401	WINDOW ASSY.LCD
F2400	AWAB0012402	WINDOW ASSY.LCD
F2400	AWAB0017801	WINDOW.LCD(SUB)
F2400	AWAB0017802	WINDOW.LCD(SUB)
F2400	AWAB0017804	WINDOW.LCD(SUB)
F2400	EUSY0240501	IC
F2400	SMPY0007201	PAM
F2400	MBJA0015601	BUTTON.DIAL
F2400	EUSY0230301	IC KG920
F2400	MBJA0016303	BUTTON.DIAL
F2400	SSAD0007828	ADAPTOR.AC-DC
F2400	ACGK0050501	COVER ASSY.FRONT
F2400	EUSY0181502	IC
F2400	SBPL0076307	BATTERY PACK.LI-ION
F2400	SVCY0003901	CAMERA
F2400	SACY0026001	PCB ASSY.FLEXIBLE
F2400	EUSY0185501	IC.PF38F3350LLZDQ0
F2400	SVLM0010301	LCD MODULE
F2400	SAGY0238110	PCB ASSY.MAIN TIM
F2400	SAGY0238106	PCB ASSY.MAIN
F3000	ACGH0038507	COVER ASSY.FOLDER(LOWER)
F3000	EXSK0005501	VCTCXO.VT-R32250FR.26 MHz
F3000	ACGJ0050407	COVER ASSY.FOLDER(UPPER)

F3000	ACGK0061507	COVER ASSY.FRONT
F3000	ACGM0062506	COVER ASSY.REAR
F3000	AWAB0019601	WINDOW ASSY.LCD
F3000	SGEY0003501	EAR PHONE/EAR MIKE SET
F3000	AKAZ0013103	KEYPAD ASSY
F3000	SBPL0076307	BATTERY PACK.LI-ION
F3000	SVCY0009701	CAMERA
F3000	SACE0035201	PCB ASSY.FLEXIBLE.SMT
F3000	SAGY0213359	PCB ASSY.MAIN(0213359)
F3000	EUSY0228401	IC
F3000	SVLM0010301	LCD MODULE
F3000	SAGY0211484	PCB ASSY.MAIN
G5300i	SNGF0001401	ANTENNA.GSM.FIXED
G5300i	SUMY0004601	MICROPHONE
G5300i	EXSK0003501	VCTCXO.CSX-532-K01
G5300i	SJMY0002802	VIBRATOR.MOTOR
G5300i	ACGM0015404	COVER ASSY.REAR
G5300i	SMPY0003901	PAM RF
G5300i	ACGK0018704	COVER ASSY.FRONT
G5300i	SSAD0007801	ADAPTOR.AC-DC
G5300i	ABGA0000801	BUTTON ASSY.DIAL
G5300i	ACGM0018903	COVER ASSY.REAR
G5300i	SBPL0065811	BATTERY PACK.LI-ION
G5300i	ACGK0022404	COVER ASSY.FRONT
G5300i	SVLM0004401	LCD MODULE
G5300i	SAGY0213402	PCB ASSY.MAIN
G5400	SNGF0001601	ANTENNA.GSM.FIXED
G5400	SUMY0004602	MICROPHONE
G5400	EXSK0003501	VCTCXO.CSX-532-K01
G5400	SJMY0005401	VIBRATOR.MOTOR
G5400	ACGH0011902	COVER ASSY.FOLDER(LOWER)
G5400	SGEY0002901	EAR PHONE/EAR MIKE SET
G5400	ACGK0020802	COVER ASSY.FRONT
G5400	MBJA0008401	BUTTON.DIAL
G5400	SMPY0004001	PAM
G5400	ACGJ0019603	COVER ASSY.FOLDER(UPPER)
G5400	SSAD0007801	ADAPTOR.AC-DC
G5400	ACGM0017701	COVER ASSY.REAR
G5400	SBPL0065835	BATTERY PACK.LI-ION 3.7 V.720 mAh
G5400	SVLM0005201	LCD MODULE
G5400	SAGY0213601	PCB ASSY.MAIN G5400
G7050	SUMY0003802	MICROPHONE
G7050	SGEY0003203	EAR PHONE/EAR MIKE SET
G7050	SJMY0006101	VIBRATOR.MOTOR
G7050	SNGF0002302	ANTENNA.GSM.FIXED
G7050	SACY0011401	PCB ASSY.FLEXIBLE
G7050	EXSK0000801	VCTCXO
G7050	ABGZ0001101	BUTTON ASSY
G7050	MCJN0015501	COVER.BACK
G7050	SMPY0004001	PAM
G7050	ACGK0028201	COVER ASSY.FRONT
G7050	SAGY0225302	PCB ASSY.KEYPAD
G7050	SBPL0065889	BATTERY PACK.LI-ION
G7050	EUSY0155201	IC
G7050	SVCY0000201	CAMERA

G7050	EUSY0160502	IC.AM50DL128CG70I
G7050	SVLM0006401	LCD MODULE
G7050	ACGQ0000501	COVER ASSY.SLIDE
G7050	SAGY0225304	PCB ASSY.MAIN GREECE FOR OPEN MARKET
G7100	ADBY0001901	DECO ASSY
G7100	ENEY0002501	CONN.RECEPTACLE
G7100	MWAF0010501	WINDOW.LCD(SUB)
G7100	SUMY0006401	MICROPHONE
G7100	EUSY0136701	IC.MAX4695EGC
G7100	EXSK0004101	VCTCXO
G7100	MDAM0002801	DECO.WINDOW(SUB)
G7100	MWAC0027301	WINDOW.LCD
G7100	SJMY0002802	VIBRATOR.MOTOR
G7100	SNGF0002003	ANTENNA.GSM.FIXED
G7100	SUVT0003501	TWO-WAY MODE SPEAKER
G7100	EDLH0008301	DIODE.LED.CHIP
G7100	SGEY0002901	EAR PHONE/EAR MIKE SET
G7100	MHFD0004301	HINGE.FOLDER
G7100	SMPY0003801	PAM RF
G7100	ACGH0015101	COVER ASSY.FOLDER(LOWER)
G7100	ACGH0015103	COVER ASSY.FOLDER(LOWER)
G7100	ACGK0025201	COVER ASSY.FRONT
G7100	ACGK0025203	COVER ASSY.FRONT
G7100	ACGM0022301	COVER ASSY.REAR
G7100	SSAD0007824	ADAPTOR.AC-DC
G7100	MBJA0009401	BUTTON.DIAL
G7100	SSAD0007801	ADAPTOR.AC-DC
G7100	SACY0012101	PCB ASSY.FLEXIBLE
G7100	ACGJ0023401	COVER ASSY.FOLDER(UPPER)
G7100	ACGJ0023403	COVER ASSY.FOLDER(UPPER)
G7100	SBPL0065880	BATTERY PACK.LI-ION 3.7 V.750 mAh
G7100	EUSY0157001	IC.AD6525XCA
G7100	SGDY0003003	DATA CABLE
G7100	SMZY0006201	MODULE.CAMERA
G7100	SVLM0005801	LCD MODULE
G7100	SAGY0223701	PCB ASSY.MAIN
KG225	SGEY0003204	EAR PHONE/EAR MIKE SET
KG225	SUMY0003802	MICROPHONE
KG225	ACGH0041904	COVER ASSY.FOLDER(LOWER)
KG225	ACGK0068101	COVER ASSY.FRONT
KG225	ACGJ0054604	COVER ASSY.FOLDER(UPPER)
KG225	SSAD0007837	ADAPTOR.AC-DC
KG225	SMPY0008301	PAM
KG225	MBJA0020607	BUTTON.DIAL
KG225	SVCY0010101	CAMERA
KG225	SBPP0016301	BATTERY PACK.LI-POLYMER
KG225	SVLM0018201	LCD MODULE
KG225	SAGY0244433	PCB ASSY.MAIN(SAGY0244433)
KG245	ACGH0041701	COVER ASSY.FOLDER(LOWER)
KG245	SGEY0003204	EAR PHONE/EAR MIKE SET
KG245	SUMY0003802	MICROPHONE
KG245	ACGJ0054301	COVER ASSY.FOLDER(UPPER)
KG245	ACGK0067701	COVER ASSY.FRONT
KG245	SSAD0007837	ADAPTOR.AC-DC
KG245	SMPY0008301	PAM

KG245	MKAZ0027403	KEYPAD
KG245	SVCY0009501	CAMERA
KG245	SVLM0019001	LCD MODULE
KG245	SAGY0244254	PCB ASSY.MAIN(SAGY0244254)
KG320	ACGA0016701	COVER ASSY.BATTERY
KG320	SGDY0010901	DATA CABLE
KG320	SJMY0008202	VIBRATOR.MOTOR
KG320	ACGM0069001	COVER ASSY.REAR
KG320	SSAD0021002	ADAPTOR.AC-DC
KG320	AHFB0000701	HINGE ASSY.SLIDE
KG320	SMPY0008301	PAM
KG320	MBJA0020701	BUTTON.DIAL
KG320	SGEY0005516	EAR PHONE/EAR MIKE SET
KG320	SACE0038301	PCB ASSY.FLEXIBLE.SMT
KG320	SVCY0011701	CAMERA
KG320	ACGK0068401	COVER ASSY.FRONT
KG320	SVLM0019201	LCD MODULE
KG320	SBPL0082801	BATTERY PACK.LI-ION
KG320	SAJY0017201	PCB ASSY.SUB
KG320	SAGY0213498	PCB ASSY.MAIN(SAGY0213498)
KG320S	ACGA0016701	COVER ASSY.BATTERY
KG320S	SGDY0010901	DATA CABLE
KG320S	SJMY0008202	VIBRATOR.MOTOR
KG320S	ACGM0069001	COVER ASSY.REAR
KG320S	SSAD0021002	ADAPTOR.AC-DC
KG320S	AHFB0000701	HINGE ASSY.SLIDE
KG320S	SMPY0008301	PAM
KG320S	MBJA0020701	BUTTON.DIAL
KG320S	SGEY0005516	EAR PHONE/EAR MIKE SET
KG320S	SACE0038301	PCB ASSY.FLEXIBLE.SMT
KG320S	SVCY0011701	CAMERA
KG320S	ACGK0068401	COVER ASSY.FRONT
KG320S	SVLM0019201	LCD MODULE
KG320S	SBPL0082801	BATTERY PACK.LI-ION
KG320S	SAJY0017201	PCB ASSY.SUB
KG320S	SAGY0213498	PCB ASSY.MAIN(SAGY0213498)
KG320S	SAGY0244446	PCB ASSY.MAIN(SAGY0244446)
KG320S	SAGY0244445	PCB ASSY.MAIN
KG800	EXSK0006201	VCTCXO
KG800	SGDY0010901	DATA CABLE
KG800	SJMY0008203	VIBRATOR.MOTOR
KG800	ACGK0077801	COVER ASSY.FRONT
KG800	ACGR0006301	COVER ASSY.SLIDE(LOWER)
KG800	ACGS0007301	COVER ASSY.SLIDE(UPPER)
KG800	AWAZ0008401	WINDOW ASSY
KG800	MBJA0020403	BUTTON.DIAL
KG800	SGEY0004211	EAR PHONE/EAR MIKE SET
KG800	MRAY0003501	RAIL
KG800	SSAD0021001	ADAPTOR.AC-DC
KG800	SACE0036601	PCB ASSY.FLEXIBLE.SMT
KG800	SBPP0015301	BATTERY PACK.LI-POLYMER
KG800	SACE0036701	PCB ASSY.FLEXIBLE.SMT
KG800	SVCY0010701	CAMERA
KG800	SAEY0048701	PCB ASSY.KEYPAD
KG800	SAEY0048601	PCB ASSY.KEYPAD

KG800	SVLM0017401	LCD MODULE
KG800	SVLM0017402	LCD MODULE
KG800	SAGY0213485	PCB ASSY.MAIN(SAGY0213485)
KG920	AFBA0002501	FRAME ASSY.SHIELD
KG920	AFBC0000501	FRAME ASSY.SHIELD(REAR)
KG920	EXSK0005002	VCTCXO.TG-5000LA(26MHZ)
KG920	MDAG0008702	DECO.FRONT
KG920	SUMY0008702	MICROPHONE
KG920	AHCZ0001401	HOLDER ASSY
KG920	SGDY0005601	DATA CABLE
KG920	ACGT0000101	COVER ASSY.UPPER
KG920	AHFA0001601	HINGE ASSY.FOLDER
KG920	SAEY0049101	PCB ASSY.KEYPAD
KG920	SSAD0007837	ADAPTOR.AC-DC
KG920	SMPY0008301	PAM
KG920	AKAZ0008007	KEYPAD ASSY
KG920	SACE0026301	PCB ASSY.FLEXIBLE.SMT
KG920	SACE0026401	PCB ASSY.FLEXIBLE.SMT
KG920	ACGU0000101	COVER ASSY.LOWER
KG920	SBPL0081701	BATTERY PACK.LI-ION
KG920	SGEY0005511	EAR PHONE/EAR MIKE SET
KG920	EUSY0218204	256MB Mini SD
KG920	SMZY0009201	MODULE.ETC
KG920	SAJY0016901	PCB ASSY.SUB
KG920	SVLY0026301	LCD
KG920	SAGY0244409	PCB ASSY.MAIN(SAGY0244409)
KG920	SVCY0005001	CAMERA
KU800	ADCA0053601	DOME ASSY.METAL
KU800	EXSK0005003	VCTCXO.TG-5001LA(19.20MHZ) U8210
KU800	ABGA0007001	BUTTON ASSY.DIAL
KU800	ACGR0007101	COVER ASSY.SLIDE(LOWER)
KU800	SACE0048401	PCB ASSY.FLEXIBLE.SMT
KU800	SAJY0019501	PCB ASSY.SUB
KU800	ACGK0076301	COVER ASSY.FRONT
KU800	EUSY0203802	IC
KU800	ACGS0008301	COVER ASSY.SLIDE(UPPER)
KU800	EUSY0246002	IC
KU800	EUSY0306301	IC
KU800	SVCY0012201	CAMERA
KU800	SAEY0050901	PCB ASSY.KEYPAD
KU800	SVCY0010201	CAMERA
KU800	SVLM0012602	LCD MODULE
KU800	EUSY0241701	IC
KU800	SAGY0244571	PCB ASSY.MAIN(SAGY0244571)
L341i	MDAD0004201	DECO.CAMERA
L341i	SJMY0007001	VIBRATOR
L341i	ACGA0006406	COVER ASSY.BATTERY
L341i	ACGF0003606	COVER ASSY.FLIP
L341i	ACGK0040401	COVER ASSY.FRONT
L341i	EXSK0003501	VCTCXO.CSX-532-K01
L341i	SGEY0002901	EAR PHONE/EAR MIKE SET
L341i	SMPY0006901	PAM
L341i	ACCZ0001401	CASE ASSY
L341i	ACHA0000701	COVER ASSY.W/O WINDOW
L341i	MBJA0015401	BUTTON.DIAL

L341i	SSAD0007828	ADAPTOR.AC-DC
L341i	ACGM0034201	COVER ASSY.REAR
L341i	SBPL0072127	BATTERY PACK.LI-ION
L341i	SGDY0004401	DATA CABLE
L341i	SVCY0002401	CAMERA
L341i	EUSY0185501	IC.PF38F3350LLZDQ0
L341i	SVLM0008301	LCD MODULE
L341i	SAGY0238101	PCB ASSY.MAIN for Greece Cosmote
L341i	SAGY0236829	PCB ASSY.MAIN for Italy Wind
L342i	ABGA0004701	BUTTON ASSY.DIAL
L342i	ACGH0034102	COVER ASSY.FOLDER(LOWER)
L342i	ACGM0053401	COVER ASSY.REAR
L342i	EXSK0005002	VCTCXO.TG-5000LA(26MHZ)
L342i	SGEY0003204	EAR PHONE/EAR MIKE SET
L342i	SJMY0002602	VIBRATOR.MOTOR
L342i	ACGJ0043201	COVER ASSY.FOLDER(UPPER)
L342i	ACGK0053501	COVER ASSY.FRONT
L342i	SMPY0007201	PAM
L342i	SSAD0007837	ADAPTOR.AC-DC
L342i	SBPL0076308	BATTERY PACK.LI-ION
L342i	SVCY0004001	CAMERA
L342i	SACY0032101	PCB ASSY.FLEXIBLE
L342i	EUSY0185501	IC.PF38F3350LLZDQ0
L342i	SVLY0024701	LCD
L342i	SAGY0222449	PCB ASSY.MAIN FOR COSMOTE
L343i	ACGH0043801	COVER ASSY.FOLDER(LOWER)
L343i	SGEY0003204	EAR PHONE/EAR MIKE SET
L343i	SUMY0003802	MICROPHONE
L343i	ACGK0074201	COVER ASSY.FRONT
L343i	AWAB0022601	WINDOW ASSY.LCD
L343i	ACGM0073202	L343i WINBK BK.BK.
L343i	SMPY0008301	PAM
L343i	ACGJ0057201	COVER ASSY.FOLDER(UPPER)
L343i	MKAZ0029801	KEYPAD
L343i	SVCY0009501	CAMERA
L343i	SBPL0077901	BATTERY PACK.LI-ION
L343i	SACE0037103	PCB ASSY.FLEXIBLE.SMT
L343i	SVLM0019002	LCD MODULE
L343i	SAGY0244461	PCB ASSY.MAIN(SAGY0244461)
L600V	ACGK0079402	COVER ASSY.FRONT
L600V	SSAD0021002	ADAPTOR.AC-DC
L600V	ACGJ0059102	COVER ASSY.FOLDER(UPPER)
L600V	EUSY0203802	IC
L600V	ABGA0007202	BUTTON ASSY.DIAL
L600V	ACGH0045302	COVER ASSY.FOLDER(LOWER)
L600V	EUSY0246002	IC
L600V	EUSY0306302	IC
L600V	SACE0043901	PCB ASSY.FLEXIBLE.SMT
L600V	SAJY0019101	PCB ASSY.SUB
L600V	SGEY0005520	EAR PHONE/EAR MIKE SET
L600V	SBPP0020102	BATTERY PACK.LI-POLYMER
L600V	ACGN0006002	COVER ASSY.CAMERA
L600V	SVCY0011901	CAMERA
L600V	EUSY0297301	IC
L600V	SVLM0021202	LCD MODULE

L600V	EUSY0279002	IC
L600V	SAGY0244603	PCB ASSY.MAIN(SAGY0244603)
M6100	EXSK0006201	VCTCXO
M6100	ABGA0005501	BUTTON ASSY.DIAL
M6100	ABGA0005601	BUTTON ASSY.DIAL
M6100	SAEY0046701	PCB ASSY.KEYPAD
M6100	SGDY0005601	DATA CABLE
M6100	ACGK0060502	COVER ASSY.FRONT
M6100	ACGR0004902	COVER ASSY.SLIDE(LOWER)
M6100	SSAD0007837	ADAPTOR.AC-DC
M6100	ACGM0061702	COVER ASSY.REAR
M6100	ACGS0005902	COVER ASSY.SLIDE(UPPER)
M6100	SSAD0007845	ADAPTOR.AC-DC
M6100	SACY0038801	PCB ASSY.FLEXIBLE
M6100	SBPP0014406	BATTERY PACK.LI-POLYMER
M6100	SVCY0007301	CAMERA
M6100	EUSY0229501	IC
M6100	SVLM0013601	LCD MODULE
M6100	SAGY0213480	PCB ASSY.MAIN(SAGY0213480)
P7200	ABFZ0004701	BRACKET ASSY
P7200	ACAZ0004201	CAP ASSY
P7200	ACGH0032501	COVER ASSY.FOLDER(LOWER)
P7200	ACGJ0044101	COVER ASSY.FOLDER(UPPER)
P7200	ACGK0050901	COVER ASSY.FRONT
P7200	ACGM0050601	COVER ASSY.REAR
P7200	ADCA0032201	DOME ASSY.METAL
P7200	AWAB0017201	WINDOW ASSY.LCD
P7200	ENBY0012401	CONNECTOR.BOARD TO BOARD
P7200	ENBY0015601	CONNECTOR.BOARD TO BOARD
P7200	ENBY0029401	CONNECTOR.BOARD TO BOARD
P7200	ENJE0003602	CONN.JACK/PLUG.EARPHONE
P7200	ENRY0004501	CONNECTOR.I/O
P7200	ENSY0001608	CONN.SIM HOLD
P7200	ENWY0002201	CONN.RF SWITCH
P7200	ENZY0016901	CONNECTOR.ETC
P7200	EUSY0229501	IC
P7200	EUSY0273701	IC
P7200	EXSK0006201	VCTCXO
P7200	EXXY0004601	X-TAL.MC-146
P7200	GMEY0008001	SCREW MACHINE.BIND
P7200	GMZZ0017501	SCREW MACHINE
P7200	GMZZ0018401	SCREW MACHINE
P7200	MBJA0016504	BUTTON.DIAL
P7200	MCCC0023701	CAP.EARPHONE JACK
P7200	MCCF0024101	CAP.MOBILE SWITCH
P7200	MCCH0053201	CAP.SCREW
P7200	MCCH0053301	CAP.SCREW
P7200	MCCH0053401	CAP.SCREW
P7200	MCCH0053601	CAP.SCREW
P7200	MDAJ0008301	DECO.HINGE
P7200	MDAJ0008401	DECO.HINGE
P7200	MGAD0088501	GASKET.SHIELD FORM
P7200	MHFD0009701	HINGE.FOLDER
P7200	MHFD0009801	HINGE.FOLDER
P7200	MTAE0022101	TAPE.WINDOW(SUB)

P7200	MWAF0026701	WINDOW.LCD(SUB)
P7200	SACE0033301	PCB ASSY.FLEXIBLE.SMT
P7200	SAGY0211497	PCB ASSY.MAIN(0211497)
P7200	SAJY0013701	PCB ASSY.SUB
P7200	SBCL0001303	BATTERY RTC
P7200	SBPP0013302	BATTERY PACK.LI-POLYMER
P7200	SEVY0001001	VARISTOR.AVLC14S02050.14 V
P7200	SEVY0003801	VARISTOR
P7200	SEVY0003901	VARISTOR
P7200	SGDY0005601	DATA CABLE
P7200	SGEY0005506	EAR PHONE/EAR MIKE SET
P7200	SJMY0007003	VIBRATOR.MOTOR
P7200	SNGF0009301	ANTENNA.GSM.FIXED
P7200	SNGF0009601	BT Chip Antenna
P7200	SPKY0022001	PCB.SIDEKEY
P7200	SPKY0022101	PCB.SIDEKEY
P7200	SUMY0010503	MICROPHONE
P7200	SURY0010401	RECEIVER
P7200	SUSY0017701	SPEAKER
P7200	SVCY0007901	CAMERA
P7200	SVLY0026501	LCD
P7200	SWWA0058001	WIRE ASSY
S5200	ABFZ0006201	BRACKET ASSY
S5200	ABFZ0007901	KAMERA KU800
S5200	ABGA0005101	BUTTON ASSY.DIAL
S5200	ABGB0002601	BUTTON ASSY.FUNCTION
S5200	ACGK0059001	COVER ASSY.FRONT
S5200	ACGM0060001	COVER ASSY.REAR
S5200	ACGR0004501	COVER ASSY.SLIDE(LOWER)
S5200	ACGS0005501	COVER ASSY.SLIDE(UPPER)
S5200	ADCA0040401	DOME ASSY.METAL
S5200	ADCA0040501	DOME ASSY.METAL
S5200	ENBY0031101	CONNECTOR.BOARD TO BOARD
S5200	ENJE0003102	CONNECTOR.EARPHONE
S5200	ENRY0005301	CONNECTOR.I/O
S5200	ENSY0014601	CONN.SOCKET
S5200	ENWY0002301	CONN.RF SWITCH
S5200	EUSY0181504	IC
S5200	EUSY0229501	IC
S5200	EUSY0245401	IC.AAT2807AIXN-4.5
S5200	EUSY0254701	IC
S5200	EUSY0259801	IC
S5200	EUSY0263001	IC
S5200	EUSY0265201	IC
S5200	EUSY0273701	IC
S5200	EXSK0006201	VCTCXO
S5200	EXXY0004602	X-TAL. MC-146
S5200	GMEY0010401	SCREW MACHINE.BIND
S5200	GMEY0010402	SCREW MACHINE.BIND
S5200	GMZZ0017701	SCREW MACHINE
S5200	MCCC0028501	CAP.EARPHONE JACK
S5200	MCCF0028401	CAP.MOBILE SWITCH
S5200	MHGF0003701	HOLDER.MIKE
S5200	MRAY0002901	RAIL
S5200	MRAY0002902	RAIL

S5200	MTAD0040501	TAPE.WINDOW
S5200	MWAC0057901	WINDOW.LCD
S5200	SACE0035601	PCB ASSY.FLEXIBLE.SMT
S5200	SAEY0046601	PCB ASSY.KEYPAD
S5200	SAGY0213317	PCB ASSY.MAIN(0213317)
S5200	SAGY0229480	PCB ASSY.MAIN
S5200	SBCL0001302	BATTERY.CELL.LITHIUM
S5200	SBPP0013601	BATTERY PACK.LI-POLYMER
S5200	SEVY0000702	VARISTOR.EVL14K02200.14 V
S5200	SEVY0003901	VARISTOR
S5200	SEVY0005501	VARISTOR
S5200	SEVY0005502	VARISTOR
S5200	SFAY0005602	FILTER. SEPERATOR
S5200	SFAY0006503	FILTER
S5200	SGEY0003505	EAR PHONE/EAR MIKE SET
S5200	SJMY0008003	VIBRATOR.MOTOR
S5200	SNGF0010301	ANTENNA.GSM.FIXED
S5200	SNGF0010801	B/T Chip.
S5200	SPKY0021301	PCB.SIDEKEY
S5200	SPKY0021401	PCB.SIDEKEY
S5200	SUMY0003802	MICROPHONE
S5200	SUMY0010502	MICROPHONE
S5200	SUSY0017901	SPEAKER
S5200	SVCY0007301	CAMERA
S5200	SVLM0013701	LCD MODULE
T5100	ACCB0000301	CASE ASSY.LOWER
T5100	ACCC0001401	CASE ASSY.UPPER
T5100	ACGA0005801	COVER ASSY.BATTERY
T5100	ACGH0021201	COVER ASSY.FOLDER(LOWER)
T5100	ACGJ0030601	COVER ASSY.FOLDER(UPPER)
T5100	ACGK0033001	COVER ASSY.FRONT
T5100	ACGM0031401	COVER ASSY.REAR
T5100	ADBY0003501	DECO ASSY
T5100	ADCA0018301	DOME ASSY.METAL
T5100	AHCZ0000901	HOLDER ASSY
T5100	AHFA0001201	HINGE ASSY.DISPLAY
T5100	AWAB0008801	WINDOW ASSY.LCD
T5100	AWAB0008901	WINDOW ASSY.LCD
T5100	EDLH0004502	DIODE.LED.CHIP
T5100	ENBY0001804	CONNECTOR.vibrator
T5100	ENBY0010501	CONNECTOR.keyboard male
T5100	ENBY0010502	CONNECTOR.keyboard female
T5100	ENBY0013406	CONNECTOR.BOARD TO BOARD
T5100	ENBY0013410	CONNECTOR.camera
T5100	ENJE0003001	CONN.Back Up Battery
T5100	ENJE0003102	CONNECTOR.EARPHONE
T5100	ENRY0000801	CONNECTOR.I/O
T5100	ENSY0007606	CONN.SOCKET sim hold
T5100	ENWY0003002	CONN.RF SWITCH
T5100	ENZY0013002	CONNECTOR.ETC
T5100	ESCY0002501	SWITCH.TACT
T5100	EXSK0005601	VCTCXO
T5100	EXSY0020002	OSCILLATOR.SG-8002CE-SC(12.288MHZ)
T5100	EXXY0015502	X-TAL.FA-238(30MHZ)
T5100	EXXY0015601	XTAL.MC-146..032768 MHz

T5100	GMZZ0001901	SCREW MACHINE (1.4 mm.3.5 mm DIA=3.1)
T5100	GMZZ0008201	SCREW MACHINE
T5100	MBHY0009201	BUMPER
T5100	MBJA0013302	BUTTON.DIAL
T5100	MBJL0012001	BUTTON.SIDE
T5100	MBJP0001001	BUTTON.SHUTTER
T5100	MCCC0014401	CAP.EARPHONE JACK
T5100	MCCH0024101	CAP.SCREW
T5100	MCCH0024201	CAP.SCREW
T5100	MCCH0024301	CAP.SCREW
T5100	MCCH0024401	CAP.SCREW
T5100	MCCH0024501	CAP.SCREW
T5100	MCCH0024601	CAP.SCREW
T5100	MCJT0001001	COVER.HINGE(LOWER)
T5100	MCJU0001101	COVER.HINGE(UPPER)
T5100	MDAJ0006401	DECO.HINGE
T5100	MDAY0007001	DECO
T5100	MDAY0007101	DECO
T5100	MFEA0004301	FRAME.SHIELD
T5100	MHFD0007701	HINGE.FOLDER
T5100	MLEA0016001	LOCKER.BATTERY
T5100	MMAA0002701	MAGNET.SWITCH
T5100	MPBH0007901	PAD.MIKE
T5100	MPBJ0013101	PAD.MOTOR
T5100	MSDC0001901	SPRING.LOCKER
T5100	MTAA0044801	TAPE.DECO
T5100	MTAA0044901	TAPE.DECO
T5100	MTAE0014201	TAPE.WINDOW(SUB)
T5100	MWAC0036001	WINDOW.LCD
T5100	MWAE0002501	WINDOW.CAMERA
T5100	MWAF0017801	WINDOW.LCD (SUB)
T5100	MWAG0006001	WINDOW.IRDA
T5100	SACY0018701	PCB ASSY.FLEXIBLE
T5100	SAEY0028601	PCB ASSY.KEYPAD
T5100	SAGY0221432	PCB ASSY.MAIN
T5100	SAGY0236810	PCB ASSY.MAIN FRANCE
T5100	SBCL0001002	BATTERY.CELL.LITHIUM
T5100	SBPL0072126	BATTERY PACK.LI-ION
T5100	SDGY0000601	DUPLEXER.GSM
T5100	SGDY0004401	DATA CABLE
T5100	SGDY0004403	DATA CABLE
T5100	SGEY0003501	EAR PHONE/EAR MIKE SET
T5100	SJMY0006103	VIBRATOR.MOTOR
T5100	SMPY0007201	PAM
T5100	SNGF0004301	ANTENNA.GSM.FIXED
T5100	SPEY0021301	PCB.KEYPAD
T5100	SSAD0007828	ADAPTOR.AC-DC
T5100	SUMY0003808	MICROPHONE
T5100	SURY0005602	RECEIVER
T5100	SUSY0006209	SPEAKER
T5100	SVCY0002601	CAMERA
T5100	SVLM0008401	LCD MODULE
U8210	ACGH0031702	COVER ASSY.FOLDER(LOWER)
U8210	ACGJ0043503	COVER ASSY.FOLDER(UPPER)
U8210	ACGK0050101	COVER ASSY.FRONT

U8210	ACGM0050001	COVER ASSY.REAR
U8210	ACGN0003301	COVER ASSY+CAMERA
U8210	ADCA0034601	DOME ASSY.METAL
U8210	AKAZ0009502	KEYPAD ASSY
U8210	AWAB0016001	WINDOW.LCD(SUB)
U8210	ENBY0004302	CONNECTOR.BOARD TO BOARD
U8210	ENBY0020401	CONNECTOR.BOARD TO BOARD
U8210	ENEY0004102	CONN.RECEPTACLE
U8210	ENJE0003602	CONN.JACK/PLUG.EARPHONE
U8210	ENSY0009901	CONN.SOCKET
U8210	ENSY0014101	CONN.SOCKET
U8210	ENWY0003001	CONN.RF SWITCH
U8210	ENZY0013006	CONNECTOR.ETC
U8210	EQBP0008701	TRANSISTOR.2SB1424
U8210	EQFP0004701	TRANSISTOR.SI3493DV
U8210	EUSY0160001	IC.TPA2005D1ZQYR
U8210	EUSY0160901	IC.RFL6200
U8210	EUSY0161001	IC.RFR6200
U8210	EUSY0202101	IC.MSM6250
U8210	EUSY0203701	IC.PM6650
U8210	EUSY0203801	IC.RTR6250
U8210	EUSY0216702	IC.TY90009C00AOGG
U8210	EXSC0008301	VCO.MQL302A1G71
U8210	EXSC0009201	VCO.MQW5V0C869M
U8210	EXSK0005003	VCTCXO.TG-5001LA(19.20MHZ) U8210
U8210	EXXY0004602	X-TAL. MC-146
U8210	EXXY0015501	X-TAL.FA-238.48 MHz
U8210	GMEY0005901	SCREW MACHINE.BIND
U8210	MBIC0000901	BUSHING.CAMERA(LEFT)
U8210	MCCC0023201	CAP.EARPHONE JACK
U8210	MCCF0023601	CAP.MOBILE SWITCH
U8210	MCCH0048001	CAP.SCREW
U8210	MCCH0048101	CAP.SCREW
U8210	MCCH0048201	CAP.SCREW
U8210	MCCH0048301	CAP.SCREW
U8210	MCCH0048401	CAP.SCREW
U8210	MCCH0048501	CAP.SCREW
U8210	MCCZ0011501	CAP
U8210	MCJA0017803	COVER.BATTERY
U8210	MDAG0010801	DECO.FRONT
U8210	MFEA0007001	FRAME.SHIELD
U8210	MGAD0081501	GASKET.SHIELD FORM
U8210	MPBG0032001	PAD.LCD
U8210	MTAD0034401	TAPE.WINDOW
U8210	MTAE0021601	TAPE.WINDOW(SUB)
U8210	MWAC0050701	WINDOW.LCD
U8210	SACY0034103	PCB ASSY.FLEXIBLE
U8210	SAEY0043701	PCB ASSY.KEYPAD
U8210	SAGY0222470	PCB ASSY.MAIN ITALY
U8210	SAGY0238177	PCB ASSY.MAIN GREECE
U8210	SAKY0005001	PCB ASSY.SIDEKEY
U8210	SBCL0001305	BATTERY.CELL.LITHIUM
U8210	SBPL0072221	BATTERY PACK.LI-ION
U8210	SDMY0000802	DUPLEXER.IMT
U8210	SEVY0001001	VARISTOR.AVLC14S02050.14 V

U8210	SFAY0004601	FILTER.SEPARATOR
U8210	SGEY0005504	EAR PHONE/EAR MIKE SET
U8210	SJMY0002602	VIBRATOR.MOTOR
U8210	SMPY0008201	PAM
U8210	SMPY0008301	PAM
U8210	SMZY0009501	MODULE.ETC
U8210	SNGF0007001	ANTENNA.GSM.FIXED
U8210	SNMF0015901	Chip_Bluetooth
U8210	SSAD0007848	ADAPTOR.AC-DC
U8210	SUMY0010701	MICROPHONE
U8210	SUVT0005601	TWO-WAY MODE SPEAKER
U8210	SVLM0011601	LCD MODULE